

Busbar System



Description	For use with	Connection	Cat. No.	List	
3-phase feed-in terminals					
Main feeding terminal	MBS32...	Terminal Capacity: 25mm ²	MD32F	\$16	
Upper Connection	MBS63...	Terminal Capacity: 50mm ²	MD63F	\$18	
Main busbar					
Modular Spacing 45mm	for 2 MBS32...+ frontal auxiliaries	63 Amp Max	Pin	MD32B02	\$10
	for 3 MBS32...+ frontal auxiliaries		Pin	MD32B03	\$16
	for 4 MBS32...+ frontal auxiliaries		Pin	MD32B04	\$22
	for 5 MBS32...+ frontal auxiliaries		Pin	MD32B05	\$25
Modular Spacing 55mm	for 2 MBS63...+ frontal auxiliaries	120 Amp Max	Pin	MD63B02	\$16
	for 3 MBS63...+ frontal auxiliaries		Pin	MD63B03	\$20
	for 4 MBS63...+ frontal auxiliaries		Pin	MD63B04	\$24
Busbar cover					
Touch guard for non used space	MBS32...	-	MD32G	\$2	
	MBS63...	-	MD63G	\$3	

Wiring Kits for Reversing Starters

Includes Line & Load Side Bus.



Part A



Cat. No.	Use with Contactor	Contactor Coil	List Price (Each Set)
MF32R05B	LS05	AC or DC	\$15.00
MF32R7B	LS4K, 5K, 7K	AC or DC	\$19.00
MF32R11B	LS11K	AC or DC	\$20.00
MF63R15B	LS15K	AC or DC	\$31.00
MF63R18B	LS18K	AC or DC	\$34.00
MF63R30A	LS22K-LS30K	AC only	\$50.00

Bases




Part B

Cat. No.	Use with Contactors	Contactor Coil	List Price (Each)
MBS32	MF32B1	LS4K, LS5K, LS7K, LS11K	2 pcs. Required \$20
	MF32B4	LS15K	\$20
MBS63	MF63B2	LS15K, LS18K	\$30
	MF63B3	LS22K-LS30K	\$30



Base Links for Reversers



Part C

Cat. No.	List Price (Each Set)
MF32C11B	\$6.00

A "Set" Includes "two pieces" and are required to tie the two bases together for a reversing application.