


AC operated *


3+4 Pole

LS4K,
LS5K,
LS5K-4/-22,
LS7K,
LS7K-4/-22,




3+4 Pole

LS11K.00,
LS11K.10
LK-HS7K aux



3+4 Pole

LS11K-4/-22,
LS15K-4/-22




LS15K
LS18K (3 Pole)

LS15K.10
LS18K.10
LK-HS7K aux


3 Pole

LS22K
LS30K
LS37K




3 Pole

LS45K
LS55K




4 Pole

LS18K-4/-22
LS30K-4/-22
LS37K-4/-22



4 Pole


LS45K-4



DC operated *


3+4 Pole

LS4K,
LS5K,
LS5K-4/-22,
LS7K,
LS7K-4/-22,




3+4 Pole

LS11K.00,
LS11K.10
LK-HS7K aux




3+4 Pole

LS11K-4/-22,
LS11K-4/-22




3 Pole

LS22K
LS30K
LS37K




3 Pole

LS45K
LS55K




4 Pole

LS18K-4/-22
LS30K-4/-22
LS37K-4/-22



4 Pole

LS45K-4



* Add 0.44 in. for Side-Mounted LK-HS8K Auxiliary Contact